


TRI-DELT

SOPHISTICATED ELECTRONICS

Box 20311 Grantville Sta. San Diego, Calif. 92120

DETECTION UNIT

TRI-DELT's Detection Unit consists of a plug-in printed circuit board and a tencontact receptacle. In operation the Detection Unit is placed in series with the track power to each block; two receptacle contacts being used for power-in from the propulsion power supply, and two receptacle contacts for power-out to the track, a ten ampere capacity. When the block is occupied by a locomotive, lighted car, or car with a resistor of 1000 ohms or less, the D-l will detect. Detection is completely independent of whether the block power is on or off. The Detection Unit has an output of 300 milliamperes at 12 volts, which may be used for Dispatcher's indicator lights, an illuminated system map, a relay, etc. provided that the rating is not exceeded. This output may be easily increased to three amperes with the addition of a power transistor stage. All D-ls may be powered by any independent 12 volt DC power supply. TRI-DELT's PS-3 Power Supply Kit furnishes sufficient power for fifteen Detection Units. It is not necessary to install a full system all at once. Detection Units may be added one block at a time. The Detection Unit is the primary building block for TRI-DELT's Three-color Signalling System.




Prices effective November 1, 1967 and subject to change without notice.

D-2 D4 DETECTION UNIT	\$ 6.95
PS-3 POWER SUPPLY KIT (sufficient for fifteen D-ls)	8.95

All components F.O.B. San Diego, Calif. - excess postage refunded.

Tri-Delt Occupation Detector D-1 Circuit board Schematic



```
C1 .1
D1 1N3492R
D2 1N3491
D3 MR2261R
D4
Q1 2N1302
O2 2N1302
O3 2N3706
Q4 2N3706
Q4 2N3706
R1 10
M2 270
R3 10
R4 27,000
R5 2,200 (1,000)
R6 10,000
R7 260
R8 27,000
R9 270
R10 4,700
```

Replace R5 with a 2,500 trim pot and adjust to 15ma through #6